Both strips of felt for waterproofing wall to be furnished by roofing contractor. Not to be mopped either top or bottom.

After copper flashing has been installed, roofing contractor to bend down copper counterflashing and solder joints.

Roof Boxes:- Roof boxes to be of 16-ounce copper 12" x 12" 6" deep, covered with brass wire screen of 12 brass wire half-inch mesh, soldered to copper box, full size of box, projecting 4" above top of gravel stop, as per detail.

The roof boxes to have soldered lead thimbles projecting through roof slab, proper distance. Thimbles to be furnished by plumber and caulked in down spouts by him.

Flashing - Miscellaneous:- Flashing around penthouse, hatchways, etc. to be same as flashing specified for roof, as detailed.

Flashing and counterflashing around flag pole, and other construction passing through roof to be as per details to be approved, using copper same as weight as specified for roof.

Waterproofing:- Starting on top within 1/2-inch of the outside edge of concrete coping blocks, paint top and inside face of concrete coping with two coats of R.I.W. paint, applied as per manufacturer's directions.

Coat the entire exposed inside face of the brick parapet walls with 1/8" thick, non-peeling, non-hardening asbestos cement, to waterproof the walls and prevent